



Installation instructions

1. Install the handwheel to the spindle and fasten it with the set screw or keyway / countersunk washer.
2. Turn the spindle to the starting point (0 position).
3. Move the position indicator "by hand" to the 0 position before mounting it.
4. Install the position indicator into the recess of the hub and fasten it with a set screw. Do not apply unnecessary excessive torque to avoid deformation of the housing!
5. Check by turning the hand knob to ensure that the starting position of the spindle coincides with the 0 position of the two pointers (EN 000.8) or respectively pointer and counter (EN 000.3). If necessary, take out and readjust the position indicator.