



### Installation instructions

1. Install the handwheel to the spindle and fasten it with the set screw.
2. Turn the spindle to the starting point (0 position).
3. Move the position indicator to the 0 position by turning the outer gear wheel.
4. Install the position indicator into the recess of the hub and fasten it with a set screw. To avoid deformation of the housing, do not apply unnecessary excessive torque!
5. Check by turning the handwheel to ensure that the starting position of the spindle coincides with the 0 position of the two pointers (EN 000.8) or respectively pointer and counter (EN 000.3). If necessary, take out and readjust the position indicator.