



### Mounting information

In order to align the edge handle with the edge of the cabinet (tolerance  $l_1 + 2 \text{ mm}$ ), the end caps, to start with, should only be loosely assembled.

To complete the mounting of the handle assembly, follow these steps:

1. Tighten the loose fitting end caps to the cabinet
2. Screw the end caps and handle extrusion tightly together using the countersunk screws