



**Mounting information**

- 1) Drill the handle housing according to the template dimensions reported in the table.
- 2) Remove all drill hole burrs before assembling the handle.
- 3) Fit the upper part of the handle into the housing.
- 4) Press down on the lower part until the handle snaps in and is completely inserted.

<b>s</b>	<b>x +0.2</b>	<b>y ±0.1</b>	<b>x ±0.2</b>	<b>y ±0.1</b>	<b>x +0.2</b>	<b>y ±0.1</b>
Wall thickness	for $b_1 = 90$		for $b_1 = 110$		for $b_1 = 120$	
0.7 ... 0.8	85	34.9	100	49.7	107.5	70.5
.02 ... .03	3.35	1.37	3.94	1.96	4.23	2.78
> 0.8 ... 1.2	85	35.1	100	50	107.5	70.8
.03 ... .05	3.35	1.38	3.94	1.97	4.23	2.79
> 1.2 ... 1.5	85	36.1	100	50.4	107.5	71.2
.05 ... .06	3.35	1.42	3.94	1.98	4.23	2.80
> 1.5 ... 2	85	36.1	100	50.7	107.5	71.5
.06 ... .08	3.35	1.42	3.94	1.99	4.23	2.81
> 2 ... 2.2	85	36.1	100	50.7	107.5	71.5
.08 ... .09	3.35	1.42	3.94	1.99	4.23	2.81