



**Mounting information**

- 1) Drill the handle housing according to the template dimensions reported in the table.
- 2) Remove all drill hole burrs before assembling the handle.
- 3) Fit the upper part of the handle into the housing.
- 4) Press down on the lower part until the handle snaps in and is completely inserted.

Identification no. 1	$x \pm 0.2$	$y \pm 0.1$	$x \pm 0.2$	$y \pm 0.1$	$x \pm 0.2$	$y \pm 0.1$
	for $b_1 = 90$		for $b_1 = 110$		for $b_1 = 120$	
Wall thickness $s$						
0.7 ... 0.8	85	34.9	100	49.7	107.5	70.5
0.02 ... 0.03	3.35	1.37	3.94	1.96	4.23	2.78
> 0.8 ... 1.2	85	35.1	100	50	107.5	70.8
0.03 ... 0.05	3.35	1.38	3.94	1.97	4.23	2.79
> 1.2 ... 1.5	85	36.1	100	50.4	107.5	71.2
0.05 ... 0.06	3.35	1.42	3.94	1.98	4.23	2.80
> 1.5 ... 2	85	36.1	100	50.7	107.5	71.5
0.06 ... 0.08	3.35	1.42	3.94	1.99	4.23	2.81
> 2 ... 2.2	85	36.1	100	50.7	107.5	71.5
0.08 ... 0.09	3.35	1.42	3.94	1.99	4.23	2.81

Identification no. 2	$x \pm 0.2$	$y \pm 0.1$	$x \pm 0.2$	$y \pm 0.1$
	for $b_1 = 110$		for $b_1 = 120$	
Wall thickness $s$				
> 0.8 ... 1.2	100,2	50,5	107,5	71,3
0.03 ... 0.05	3,95	1,99	4,23	2,81
> 1.2 ... 1.5	100	51,4	107,5	71,8
0.05 ... 0.06	3,94	2,02	4,23	2,83

1.1  
1.2  
1.3  
1.4  
2.1  
2.2  
2.3  
2.4

